

BAUCO® air

GRILLE CORE REMOVAL AND FINISHING INSTRUCTIONS

Finishing around the grilles in access panels and other drywall surfaces:

- Remove the grille core
- Finish the access panel with gypsum compound
- Paint
- Reinsert grille core

REMOVE GRILLE CORE

To finish an access panel with **BAUCO® air** grille you will need to remove the grille core from the door leaf. Press firmly on the top edge of the grille to release the concealed spring latches. The grille will tilt forward. Lift it upwards and angle it out of the opening. Set aside.

FINISH DOOR LEAF

Apply filler compound to the door leaf up to the height of the top of the panel and grille aluminum frame.

Sand and repeat until desired finish level.

To reinstall grille core into the opening, fit bottom of grille (flat steel hardware) into the opening. Press opposite side firmly into the opening to engage concealed spring touch latches.

